



**Concrete Block Detail**

scale 1:2

**Notes:**

- All dimensions are in mm. DO NOT SCALE OFF THESE DRAWINGS
- This detail sheet is to assist in the installation of an **internally located, frameless finish** to a Mode KS1150 Gas Fire.
- Use care when block laying to avoid damaging powdercoated black fireplace reveals - protect fire from damage and use a damp sponge to remove excess mortar.
- Black fireplace reveals must be able to be removed - ensure any adhesive or mortar is kept clear.
- A CMU lintel can be used instead of MS Lintel in accordance with design and building code requirements.
- Allow for construction tolerance when setting out the opening within the block/CMU wall.
- This technical sheet must be read in conjunction with the Mode KS1150 Installation Manual, the latest version can be found on our website at [www.stokefires.com](http://www.stokefires.com)

GENERAL CONSTRUCTION AND FINISHES SHOWN INDICATIVE ONLY

Contact the ESCEA Architectural Advisory Team for assistance with the specification of this fire - [aa@escea.com](mailto:aa@escea.com)