KS1150 Frameless Finish with Tile

MODE

Prolonged unprotected exposure to heat may be detrimental to the appearance or long term performance of the wall lining.

line of wall framing around the fire		
10mm JH villaboard		
scavenger head self-tapping metal screw and adhesive fixing to wall lining fixing bracket		
wall lining fixing bracket		
porcelain tile withsanded grout		
maintain 6mm (+/-2mm) gap between wall finish and trim of the fire		
KS1150 gas fireplace with standard 22mm black reveal		
fireplace glass		
	<u>Tile Detail</u>	scale 1:1

Notes:

- All dimensions are in mm. DO NOT SCALE OFF THESE DRAWINGS
- This detail is to assist in the installation of a **frameless finish** to a Mode KS1150 Gas Fireplace. They offer pathways for protection of heat sensitive linings and finishes.
- This detail will use the extended cabinetry trim kit to protect overhanging cladding edges at the opening of the fire.
- Escea recommends when using these finishing methods that 10mm Fibre Cement Sheet is used.
- Use care when grouting tiles to avoid scratching black fireplace reveals.
- Black fireplace reveals must be able to be removed ensure any adhesive or compound is kept clear.
- This technical sheet must be read in conjunction with the Mode K\$1150 Installation Manual, the latest version can be found on our website at *www.stokefires.com*

GENERAL CONSTRUCTION AND FINISHES SHOWN INDICATIVE ONLY

Contact the ESCEA Architectural Advisory Team for assistance with the specification of this fire - aa@escea.com